

Operation of Pipework Package Unit

CONTENT

DESCRIPTION OF PIPEWORK PACKAGE UNIT	3
General view	3
Encoding.....	3
Installation diagram	4
DANFOSS AMB 162 ELECTRICAL ACTUATOR	6
Description, main data	6
Electrical wiring	6
The installation of electrical actuator.....	7
„Right-side“ working mode.....	7
„Left-side“ working mode.....	9
ELECTRICAL WATER PUMP	10
Operating knob.....	10
Operating button.....	10
Control modes.....	10
Variable differential pressure ($\Delta p-v$).....	10
Constant differential pressure ($\Delta p-c$).....	10
Constant pump speed.....	10
Dimensions and mass of Pipework Package Unit.....	12



This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive (2002/96/EC) and your national law. This product should be handed over to a designated collection point, or to an authorised collection site for recycling waste electrical and electronic equipment (EEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, approved WEEE scheme or your household waste disposal service.

DESCRIPTION OF PIPEWORK PACKAGE UNIT

Pipework Package Unit PPU is used for the adjustment of thermal power of water heaters, i. e. for the adjustment of thermal medium debit via the heater and support the temperature of supplied air.

Pipework Package Unit PPU must be used in a dry room where the temperature from +5 °C to +50 °C is maintained.



In order to install PPU unit outdoors, it must be additionally protected against freezing (e.g. by placing the unit in a thermally insulated cabinet or box) and ensuring constant circulation of hot water or using an antifreeze mixture of water and glycol.

The adjusted thermal medium must be free of dry solids (sand, dirt) or chemical substances as they may harm the mixing unit. No modifications of Pipework Package Unit are allowed because in such case the warranty shall be cancelled.

Prior the installation, the Pipework Package Unit PPU should be transported and stored in original packing. During the transportation, packing protects the Pipework Package Unit against dirt. During the transportation, the product should be protected against mechanical damage, for instance, against impact, falling or vibration. In case of damage due to improper transportation or storage, the warranty shall not apply.


Pipework Package Unit PPU should be installed in a easy accessible location for service and maintenance. Electric wires should not come in contact with the surface of the mixing unit. Pipework Package Unit should be connected to the equipment ensuring its control. The pump rotation can be chosen of three levels. They are adjusted with a switch on the pump body.



PPU – hydraulic tests were not performed with Pipework Package Units!

General view

General view of pipework package unit:



Encoding

PPU – HW - 3R – 40 - 25,0 - W3


1	2	3	4	5	6
PPU	HW	3R	40	25,0	W3

1. PPU – “Pipework Package Unit”
2. HW – for heating
CW – for cooling
3. R – „Right-side” installation (heat transfer medium from right side)
L – „left-side” installation (heat transfer medium from left side)
3 – 3-way mixing valve is used
4. DN – nominal diameter of pipework
5. Nominal water flow through valve (K_{vs})
6. Water pump code


Installation diagram

The installation diagrams are presented below.


"Left-side" installation




"Right-side" installation



"Left-side" installation



"Right-side" installation



1. Circulation pump
2. Thermometer
3. Manometer

4. One-way valve
5. Three-way valve
6. Actuator

7. Ball valve
8. Balancing valve
9. Filter

RECOMMENDATION: It is recommended to use dismantle joints during installation of Pipework Package Unit in case of emergency disassemble.

DANFOSS AMB 162 ELECTRICAL ACTUATOR

Description, main data


AMB 162 actuator is used for temperature control in central heating systems together with 3-way and 4-way rotary valves.

Main data:


- Supply voltage 24 V a.c.
- voltage signal of 0-10 V or 2-10 V.
- Opportunity to control manually.
- With electrical actuator limit of 90°.



Electrical wiring




The actuator is wired as the example above depending on actuator type.




The actuator is switched to automatic mode, controlled by electrical signal, if manual mode was switched on. When automatic mode is switched on, the handle should not be turned by hand. This may damage the actuator.

The installation of electrical actuator

Actuator should be assembled as shown in a picture below.





The actuator cannot be mounted upside-down (look at the picture below).



„Right-side“ working mode


The position of axle before installation

Make sure that valve is in correct position before installation. The valve should be in transitional position. The plane on the axis indicates the position of valve. Position indicator should be also mounted in correct position as shown in the picture.



DIP switch setting

DIP switch should be seen when the cover of actuator is removed. Make sure the switch No. 4 is in ON position.



Mounting the handle

Actuator is finished assembling by putting the handle in position as shown in the picture.



The electrical actuator is ready for use.



„Left-side“ working mode


The position of axle before installation

Make sure that valve is in correct position before installation. The valve should be in transitional position. The plane on the axis indicates the position of valve. Position indicator should be also mounted in correct position as shown in the picture.



DIP switch setting

DIP switch should be seen when the cover of actuator is removed. Make sure the switch No. 4 is in OFF position.



Mounting the handle

Actuator is finished assembling by putting the handle in position as shown in the picture.

The electrical actuator is ready for use.



ELECTRICAL WATER PUMP¹

High-efficiency circulation pump for hot water heating systems with integrated differential pressure control. Control mode and differential pressure (delivery head) are adjustable. The differential pressure is controlled via the pump speed.

Operating knob

- Select control mode.
- Set differential pressure setpoint H.
- Activate the venting function.





The venting function vents the pump automatically.
The heating system is not vented.

Operating button²

Select control mode or speed by pressing operating button. Indication light will appear near selected mode.

Press and hold for 3 seconds to activate pump venting function.




Control modes

Variable differential pressure ($\Delta p-v$)

The differential pressure setpoint H is increased linearly from $\frac{1}{2} H$ to H across the volume flow range. The differential pressure generated by the pump is adjusted to the corresponding differential pressure setpoint.


Note: Recommended for heating systems with radiators to reduce the flow noises at the thermostatic valves.



Constant differential pressure ($\Delta p-c$)

The differential pressure is kept constant at the differential pressure setpoint H.


Note: Recommended for underfloor heating, large-sized pipes as well as all applications without changeable pipe system curve (e.g. storage charge pumps).



Constant pump speed³

Recommended for systems with fixed system resistance requiring a constant volume flow.


The pump runs in three prescribed fixed speed stages (I, II, III).



¹ This description/instructions is not valid if a pump of an alternative supplier is chosen for manufactured PPU unit. The pump instructions is included in the kit.

² Only for Wilo-Strata series pumps.

³ Only for Wilo-Strata series pumps.



Dimensions and mass of Pipework Package Unit.

Dimensions, mm	1	PPU-0,4-W2	PPU-0,63-W2	PPU-1,0-W2	PPU-1,6-W2	PPU-2,5-W2	PPU-4,0-W2	PPU-6,3-W2	PPU-10,0-W3 PPU-10,0-W5	PPU-16,0-W3	PPU-25,0-W3 PPU-25,0-W5	PPU-40,0-W7
	2	PPU-0,4-W3	PPU-0,63-W3	PPU-1,0-W3	PPU-1,6-W3	PPU-2,5-W3	PPU-4,0-W3 PPU-4,0-W4 PPU-4,0-W5	PPU-6,3-W3 PPU-6,3-W4 PPU-6,3-W5	PPU-10,0-W6	PPU-16,0-W5	PPU-25,0-W7	PPU-40,0-W8
	3									PPU-16,0-W6	PPU-25,0-W8	PPU-40,0-W9
	4									PPU-16,0-W7		
A	1			426			500	523	485	580	594	653
	2			498			510	485	527	584	537	683
	3									504	570	616
	4									564		
B	1			439			457	490	490	503	530	557
	2											
	3											
	4											
C	1			322			312	376	376	372	403	429
	2											
	3											
	4											
D	1			4			88	48	10	107	92	123
	2			76			98	10	52	111	35	153
	3									32	68	87
	4									92		
G (DN)				1/2" (15)			3/4" (20)	1" (25)		1 1/4" (32)	1 1/2" (40)	2" (50)

UAB KOMFOVENT

TECHNINĖS PRIEŽIŪROS SKYRIUS / SERVICE AND SUPPORT

Tel. +370 5 200 8000
service@komfovent.com

ООО «КОМФОВЕНТ»

Россия, Москва
ул. Выборгская д. 16,
стр. 1, 2 этаж, 206 офис
Тел. +7 499 673 22 73
info.oka@komfovent.com
www.komfovent.ru

ООО «КОМФОВЕНТ»

390017 г. Рязань
Ряжское шоссе, 20 литера Е, пом Н6
Тел.: +7 491 255 95 71
info.oka@komfovent.com
www.komfovent.ru

ИООО «Комфовент»

Республика Беларусь, 220125 г. Минск,
ул. Уручская 21 – 423
Тел. +375 17 266 5297, 266 6327
info.by@komfovent.com
www.komfovent.by

Komfovent AB

Ögärdesvägen 12B
433 30 Partille, Sverige
Тел. +46 31 487 752
info_se@komfovent.com
www.komfovent.se

Komfovent Oy

Muuntotie 1 C1
FI-01 510 VANTAA
Тел. +358 0 408 263 500
info_fi@komfovent.com
www.komfovent.com

Komfovent GmbH

Konrad-Zuse-Str. 2a, 42551 Velbert,
Deutschland
Тел. +49 0 2051 6051180
info@komfovent.de
www.komfovent.de

SIA Komfovent

Bukaišu iela 1, LV-1004 Rīga
Тел. +371 24 664433
info@komfovent.lv
www.komfovent.lv

Vidzemes filiāle

Alejas iela 12A, LV-4219 Valmiermuiža,
Valmieras pagasts, Burtnieku novads
Тел. +371 29 358 145
kristaps.zaicevs@komfovent.com
www.komfovent.lv

www.komfovent.com

PARTNERS

AT	J. PICHLER Gesellschaft m. b. H.	www.pichlerluft.at
BE	Ventilair group	www.ventilairgroup.com
	ACB Airconditioning	www.acbairco.be
CZ	REKUVENT s.r.o.	www.rekuvent.cz
CH	WESCO AG	www.wesco.ch
	SUDCLIMATAIR SA	www.sudclimatair.ch
CH / LI	CLIMAIR GmbH	www.climair.ch
	Trivent AG	www.trivent.com
DK	Øland A/S	www.oeland.dk
EE	BVT Partners	www.bvtpartners.ee
FR	ATIB	www.atib.fr
HR	Microclima	www.microclima.hr
HU	AIRVENT Légtechnikai Zrt.	www.airvent.hu
	Gevent Magyarország Kft.	www.gevent.hu
	Merkapt	www.merkapt.hu
IR	Fantech Ventilation Ltd	www.fantech.ie
IS	Blikk & Tækniþjónustan ehf	www.bogt.is
	Hitataekni ehf	www.hitataekni.is
IT	Icaria srl	www.icariavmc.it
NL	Ventilair group	www.ventilairgroup.com
	DECIPOLE-Vortvent	www.vortvent.nl
	CLIMA DIRECT BV	www.climadirect.com
NO	Ventilution AS	www.ventilution.no
	Ventistål AS	www.ventistal.no
	Thermo Control AS	www.thermocontrol.no
PL	Ventia Sp. z o.o.	www.ventia.pl
SE	Nordisk Ventilator AB	www.nordiskventilator.se
SI	Agregat d.o.o	www.agregat.si
SK	TZB produkt, s.r.o.	www.tzbprodukt.sk