



B1	Supply air temperature sensor	DK1	Frequency converter	HM	Humidifier	S2	Cooling water pump
B3	Outdoor temperature sensor	DX1,DX2,DX3	Direct expansion cooler	PF	Air filter	TG1	Hot water mixing valve actuator
B5	Return water sensor	FG1	Supply air damper actuator	PD1	Connection box	TG2	Cold water mixing valve actuator
B6	Air pressure sensor	FG4	Recirculation air damper actuator	QS1	Main switch	VP	Remote control panel
B8	Airquality, CO ₂ sensor	HE1	Electric heater	RG1	Main controller	V1	Supply air fan
B9	Humidity sensor	HE2	Electric heater	RG2-RG3	Extension modules	FUNCTIONAL DIAGRAM VERSO PRO S	
CW	Water cooler	HW	Water heater coil	S1	Heating water pump		